


Overview



- | | |
|-------------------------|--------------------------|
| 1. XDT Radar | 5. MPH Indication light |
| 2. XDT Radar Footplate | 6. Power/Switch Button |
| 3. MAIN LED-Lights | 7. Status LED |
| 4. KPH Indication light | 8. Charging Port (USB-C) |

Quick start guide

Step 1

Press and hold the button to power on. The radar LED will turn on shortly to indicate standalone mode.

Step 2 (optional)

Change between kilometers per hour (KMH) and miles per hour (MPH) by pressing the power button 2 times shortly.

Step 3


Place the radar 0,5 meters centrally behind the goal, or 0,5 meters right/left of the goal post

Step 4

Start shooting! The radar will show the registered speed for 5 seconds.

Charging

To charge XDT Radar, connect a USB adapter (not included) to the charging port using the power cable. The battery is fully charged when the battery indicator turns off.



Safety considerations

- The product is not recommended for use by children under 8 years of age.
- Read instructions thoroughly and keep for future reference.
- This device contains electrical equipment that could cause injury if not handled properly.
- This toy contains a battery that is non-replaceable. Do not attempt to replace the battery or open the enclosure or disassemble the device. Doing so can result in a safety hazard and will void the warranty.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Do not use the device if it is damaged. Substances in the device and its battery may harm the environment or cause injury if handled or disposed improperly.
- Do not dispose the device in a fire. The battery could explode.
- Do not expose the device to extremely high or low temperatures or heavy rain.
- The device is water splash-proof only (IPX4). Do not immerse in water.
- Store the product in a dry and moisture free environment.
- Keep a safe distance to other people and objects. Collision hazard. Use of 1 or more devices by several people within the same playing area can cause serious injuries.
- Usage of the device while under the influence of alcohol or drugs is prohibited.
- Do not charge the device while it is wet.
- Do not use the device while charging it.

